Instruction Manual ENG

DVD HOME THEATER SYSTEM

HT-TXQ120



SAMSUNG ELECTRONICS CANADA, INC.

HEADQUARTERS
55 Standish Court Mississauga, Ontario L5R 4B2 Canada
TEL: 1-905-542-3535
www.samsung.ca

SERVICE DIVISION
55 Standish Court Mississauga, Ontario L5R 4B2 Canada
1-800-SAMSUNG (1-800-726-7864)

AH68-01959S
REV: 00

Safety Warnings

CAUTION
RISK OF ELECTRIC SHOCK.
DO NOT OPEN

TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE REAR COVER (or BACK).
NO USER SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE
PERSONNEL.

This symbol indicates “dangerous voltage” inside the product that presents a risk of electric shock or personal injury.

This symbol indicates important instructions accompanying the product.

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
PRODUCTO LASER CLASE 1

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION : INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.

Note to CATV system installer

This reminder is provided to call the CATV system installer’s attention to Section 820~40 of the NEC which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

WARNING

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION

Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

Precautions





Ensure that the AC power supply in your house complies with the identification sticker located on the back of your player or subwoofer.
Install your player or subwoofer horizontally, on a suitable base (furniture), with enough space around it for ventilation (3~4inches).
Make sure the ventilation slots are not covered. Do not stack anything on top of the player or subwoofer. Do not place the player or subwoofer on amplifiers or other equipment which may become hot. Before moving the player, ensure the disc insert hole is empty.
This player is designed for continuous use. Switching off the DVD player to the stand-by mode does not disconnect the electrical supply.
In order to disconnect the player completely from the power supply, remove the main plug from the wall outlet, especially when left unused for a long period of time.



During thunderstorms, disconnect the AC main plug from the wall outlet.
Voltage peaks due to lightning could damage the unit.
The Mains plug is used as a disconnect device and shall stay readily operable at any time.



Do not expose the unit to direct sunlight or other heat sources.
This could lead to overheating and malfunction of the unit.



Protect the player from moisture (i.e. vases) , and excess heat (e.g.fireplace) or equipment creating strong magnetic or electric fields (i.e.speakers...). Disconnect the power cable from the AC supply if the player malfunctions. Your player is not intended for industrial use.

Use of this product is for personal use only.

Condensation may occur if your player or disc has been stored in cold temperatures.

If transporting the player during the winter, wait approximately 2 hours until the unit has reached room temperature before using.



The batteries used with this product contain chemicals that are harmful to the environment.

Do not dispose of batteries in the general household trash.

Features

Multi-Disc Playback & FM Tuner

The HT-TXQ120 combines the convenience of multi-disc playback capability, including DVD-AUDIO, DVD-VIDEO, SACD, CD, MP3-CD, WMA-CD, DivX, CD-R/RW, and DVD±R/RW, with a sophisticated FM tuner, all in a single player.

DVD-Audio compatible

Experience the super high-quality audio performance of DVD-Audio. The on-board 24-bit/192kHz DAC enables this player to deliver exceptional sound quality in terms of dynamic range, low-level resolution and high-frequency detail.

USB Host Play

You can enjoy media files such as pictures, movies and tunes saved in an MP3 player, digital camera, or USB memory by connecting the storage device to the USB port of the home theater.

SACD Play

You can listen to high quality multi-channel sound that exceeds regular CD playback.

Dolby Pro Logic II

Dolby Pro Logic II is a form of multi-channel audio signal decoding technology that improves upon existing Dolby Pro Logic.

DTS (Digital Theater Systems)

DTS is an audio compression format developed by Digital Theater Systems Inc. It delivers full-frequency 5.1 channel sound.

TV Screen Saver Function

The HT-TXQ120 automatically brightens and darkens your TV screen after 3 minutes in the stop mode.
The HT-TXQ120 automatically switches itself into the power saving mode after 20 minutes in the Screen Saver mode.

Power Saving Function

The HT-TXQ120 automatically shuts itself off after 20 minutes in Stop mode.

Customized TV Screen Display

The HT-TXQ120 allows you to select your favorite image during JPEG or DVD playback and set it as your background wallpaper.

HDMI

HDMI transmits DVD video and audio signals simultaneously, and provides a clearer picture.
The 1080p resolution provides even clearer pictures.

Contents

PREPARATION

Safety Warnings 2
Precautions....3
Features....4
Notes on Discs 6
Description....8

CONNECTIONS

Speaker Installation 12
Installing the DVD player....13
Connecting the Speakers 14
Connecting the Optional Wireless Receiving Amplifier 17
Connecting the Video Out to TV....19
Connecting the HDMI IN/OUT....20
HDMI Function....21
Connecting Audio from External Components 22
Connecting the FM Antenna....23

OPERATION

Before Reading the User's Manual 24
Before Using Your Home Theater 25
Disc Playback....26
SACD (Super Audio CD) Playback....27
MP3/WMA-CD Playback 28
JPEG File Playback....29
DivX Playback 30
Using the Playback Function....32
Displaying Disc Information 32
Checking the Remaining Time....33
Fast Playback 33
Slow Playback 33
Skipping Scenes/Songs....34
Repeat Playback....35
To Select a Repeat Playback Mode in the Disc Information Screen 35
A-B Repeat Playback....36
Step Function....36
Angle Function....37
Zoom (Screen Enlarge) Function 37
EZ VIEW Function 38
Bonus Group....38
Navigating Pages....38
Audio Language Selection Function....39
Subtitle Language Selection Function 39
Moving Directly to a Scene/Song 40
Using the Disc Menu 41
Using the Title Menu....41
Playing Media Files using the USB HOST feature....42

SETUP

Settings....44
Setting the Language....44
Setting TV Screen type....45
Setting Parental Controls (Rating Level) 46
Setting the Password....46
Setting the Wallpaper 47
To Select One of the 3 Wallpaper Settings you've made....47
DVD Playback Mode....48
DivX (R) registration 48
SACD Playback Mode 49
Setting the Speaker Mode 49
Setting the Delay Time 50
Setting the Test Tone 51
Setting the Audio....52
Setting the DRC (Dynamic Range Compression) 53
Setting the AV SYNC 53
Dolby Pro Logic II Mode 54
Dolby Pro Logic II Effect....55

MISCELLANEOUS

Auto Sound Calibration Setup 56
Live Surround Mode 58
Listening to Radio....60
Convenient Functions....63
Operating a TV with the Remote Control 62
Troubleshooting 64
Cautions on Handling and Storing Discs....66
Language Code List 67
USB Host Feature Supported Products 68
Specifications....69

Notes on Discs

DVD (Digital Versatile Disc) offers fantastic audio and video, thanks to Dolby Digital surround sound and MPEG-2 video compression technology. Now you can enjoy these realistic effects in the home, as if you were in a movie theater or concert hall.

DVD players and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.
The Region Number for this player is given on the rear panel of the player.
(Your DVD player will only play DVDs that are labeled with identical region codes.)

Playable Discs

Disc Type	Mark (Logo)	Recorded Signals	Disc Size	Max. Playing Time
DVD-AUDIO DVD-VIDEO		Audio + Video	5 inch	Approx. 240 min. (single-sided)
				Approx. 480 min. (double-sided)
			3 1/2 inch	Approx. 80 min. (single-sided)
				Approx. 160 min. (double-sided)
AUDIO-CD		Audio	5 inch	74 min.
			3 1/2 inch	20 min.
Divx		Audio + Video	5 inch	74 min.
			3 1/2 inch	20 min.
Super Audio CD		Audio	5 inch	74 min.

Do not use the following types of disc!

- LD, CD-G, CD-I, CD-ROM and DVD-ROM discs cannot be played on this player.
  If such discs are played, a **<WRONG DISC FORMAT>** message appears on the TV screen.
- DVD discs purchased abroad may not play on this player.
  If such discs are played, a **<CAN'T PLAY THIS DISC PLEASE, CHECK REGION CODE>** message appears on the TV screen.

Copy Protection

- **Many DVD discs are encoded with copy protection. Because of this, you should only connect your DVD player directly to your TV, not to a VCR. Connecting to a VCR results in a distorted picture from copy-protected DVD discs.**
- This product incorporates copyright protection technology that is protected by methods claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Disc Recording Format

This product does not support Secure (DRM) Media files.

CD-R Discs

- Some CD-R discs may not be playable depending on the disc recording device (CD-Recorder or PC) and the condition of the disc.
- Use a 650MB/74 minute CD-R disc.
  Do not use CD-R discs over 700MB/80 minute as they may not be playback.
- Some CD-RW (Rewritable) media, may not be playable.
- Only CD-Rs that are properly "closed" can be fully played. If the session is closed but the disc is left open, you may not be able to fully play the disc.

CD-R MP3 Discs

- Only CD-R discs with MP3 files in ISO 9660 or Joliet format can be played.
- MP3 file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- Use discs recorded with a compression/decompression data rate greater than 128Kbps.
- Only files with the <mp3> and extensions can be played.
- Only a consecutively written multisession disc can be played. If there is a blank segment in the Multisession disc, the disc can be played only up to the blank segment.
- If the disc is not closed, it will take longer to begin playback and not all of the recorded files may be played.
- For files encoded in Variable Bit Rate (VBR) format, i.e. files encoded in both low bit rate and high bit rate (e.g., 32Kbps ~ 320Kbps), the sound may skip during playback.
- A maximum of 500 tracks can be played per CD.
- A maximum of 300 folders can be played per CD.

CD-R JPEG Discs

- Only files with the <jpg> extensions can be played.
- If the disc is not closed, it will take longer to start playing and not all of the recorded files may be played.
- Only CD-R discs with JPEG files in ISO 9660 or Joliet format can be played.
- JPEG file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- Only a consecutively written multisession disc can be played. If there is a blank segment in the multisession disc, the disc can be played only up to the blank segment.
- A maximum of 9,999 images can be stored on a single CD.
- When playing a Kodak/Fuji Picture CD, only the JPEG files in the picture folder can be played.
- Picture discs other than Kodak/Fuji Picture CDs may take longer to start playing or may not play at all.

DVD±R/RW, CD-R/RW DivX Discs

- Since this product only provides encoding formats authorized by DivX Networks, Inc., a DivX file created by the user might not play.
- Software updates for incompatible formats are not supported.
  (Example: QPEL, GMC, resolution higher than 720 X 480 pixels, etc.)
- Sections with a high frame rate might not be played while playing a DivX file.
- For more information about the formats authorized by DivX Networks, Inc., please visit "www.divxnetworks.net".

<FRONT>



<REAR>



5
6
7
8
9
10
11



20
21
22

Operation Range of the Remote Control

The remote control can be used up to approximately 23 feet (7 meters) in a straight line. It can also be operated at a horizontal angle of up to 30° from the remote control sensor.

Speaker Installation

How to Install the Speaker and the Stand



1 Turn the stand upside down and mount it on the stand base.

2 Tighten 4 screws on the bottom side of the stand base.

3 Place the stand on the floor and tighten 2 screws on the back of the stand.

4 Mount the speaker on the stand.

5 Tighten 2 screws on the back of the speaker.

6 This is the successfully assembled speaker.

! • Make sure that the speaker is installed on a flat and stable area. Otherwise it may be easily knocked over.

Speaker Packages

Please confirm that all the following contents are included in the package.



Front/Rear Speaker (4EA)

* Front speakers and rear speakers are packaged separately as shown in the diagram.



Center Speaker

Subwoofer Speaker

Speaker Accessories

Speaker Cable (5EA)

Installing the DVD player



1 Mount the stand on the stand base and tighten 4 screws on the bottom side of the stand base.

2 Loosen 2 screws at the bottom of the back cover.

3 Detach the back cover by lifting it up.

4 Secure the main unit by aligning 4 protruding points on the back of the main unit with the fixing holes on the stand.

5 Tighten 2 screws in the middle of the stand.

6 Open a Toroidal Ferrite Core by pulling it upward. Wrap it around of the system connection cable so it will be next to the DVD Player. Close it back by pressing it all the way down until you hear a clicking sound.

7 Push the cable into the cable fixing hole in the stand.

8 To fix the cable, insert the cable holder into the hole on the stand.

9 Let the cable run through the hole at the bottom of the back cover and close the back cover.

10 Tighten 2 screws at the bottom of the back cover.

11 Open a Toroidal Ferrite Core by pulling it upward. Wrap it around of the system connection cable so it will be next to the DVD Player. Close it back by pressing it all the way down until you hear a clicking sound.

• The Toroidal Ferrite Core is designed to reduce electromagnetic waves that may cause interference.

Stand Packages

Please confirm that all the following contents are included in the package.



Connecting the Speakers

Before moving or installing the product, be sure to turn off the power and disconnect the power cord.

Position of the DVD Player

- Place it on a stand or cabinet shelf, or under the TV stand.

Front Speakers (L) (R)

- Place these speakers in front of your listening position, facing inwards (about 45°) toward you.
- Place the speakers so that their tweeters will be at the same height as your ear.
- Align the front face of the front speakers with the front face of the center speaker or place them slightly in front of the center speakers.

Center Speaker (C)

- It is best to install it at the same height as the front speakers.
- You can also install it directly over or under the TV.

Selecting the Listening Position

The listening position should be located about 2.5 to 3 times the distance of the TV's screen size away from the TV. Example :
For 32" TVs 2~2.4m (6~8feet)
For 55" TVs 3.5~4m (11~13feet)

Rear Speakers (SL) (SR)

- Place these speakers behind your listening position.
- If there isn't enough room, place these speakers so they face each other.
- Place them about 60 to 90cm (2 to 3feet) above your ear, facing slightly downward.

  * Unlike the front and center speakers, the rear speakers are used to handle mainly sound effects and sound will not come from them all the time.

Subwoofer (SW)

- The position of the subwoofer is not so critical. Place it anywhere you like.

Connect the System

Subwoofer Functions

Subwoofer : With a built-i

If you attach a Toroidal fe
interference from radio sig



Resetting the Wireless Receiving Module

Reset the system if a communication failure occurs, or if the Link indicator (blue LED) on the wireless receiver does not light up and the "REAR CHECK" message blinks on the main unit's display.
Reset the system while the main unit and the wireless receiver module (SWA-3000) are in Power Standby mode.



1 With the main unit turned off, press and hold the remote control's **REMAIN** button for 5 seconds.

- The STANDBY LED on the front panel of the wireless receiver module blinks.

2 With the wireless receiver module turned on, use a ball point pen or a toothpick to press the **RESET** button on the back of the unit.

- The STANDBY LED on the front panel of the wireless receiver module blinks 2 Times.

3 Turn on the main unit.

- The LINK LED of the wireless receiver module is lit and the Reset is completed.
- If Power Standby mode continues, repeat Steps 1 to 3 above.

- When the wireless receiving module setting is complete, no audio signal is output from the Rear Speaker Output Connector on the back of the subwoofer.
- The wireless receiving antenna is built into the wireless receiver module. Keep the unit away from water and moisture.
- For optimal listening performance, make sure that the area around the wireless receiver module location is clear of any obstructions.
- Sound will be heard from the wireless rear speakers in DVD 5.1-CH or Dolby Pro Logic II mode only.
- In 2-CH mode, no sound will be heard from the wireless rear speakers.

- Place the wireless receiver module at the rear of the listening position. If the wireless receiver module is too close to the main unit, some sound interruption may be heard due to interference.
- If you use a device such as a microwave oven, wireless LAN Card, Bluetooth equipment, or any other device that uses the same frequency (2.4GHz) near the system, some sound interruption may be heard due to interference.
- The transmission distance of a radio wave is about 33 feet, but may vary depending on your operating environment. If a steel-concrete wall or metallic wall is between the main unit and the wireless receiver module, the system may not operate at all, because the radio wave cannot penetrate metal.

Connecting the Video Out to your TV

Choose one of the three methods for connecting to a TV.



METHOD 1 : HDMI ..... (Best Quality)

Connect the supplied HDMI cable from the HDMI OUT jack on the back of the Main Unit to the HDMI IN jack on your TV.

METHOD 2 : Component ..... (Better Quality)

If your television is equipped with Component Video inputs, connect a component video cable(not supplied) from the Component Video Output (PR, PB and Y) Connectors on the back of the subwoofer to the Component Video Input Connectors on your TV.

METHOD 3 : Composite Video ..... (Good Quality)

Connect the supplied video cable from the VIDEO OUT jack on the back of the subwoofer to the VIDEO IN jack on your TV.

- This product only operates in 480i for Component Output.
- After making the video connection, set the Video input source on your TV to match the corresponding Video output (HDMI, Component or Composite) on your Home theater.
  See your TV owner's manual for more information on how to select the TV's Video Input source.

Connecting the HDMI IN/OUT

HDMI (High-Definition Multimedia Interface) is a digital interface that enables transmitting digital video and audio over a single cable. In addition, it enables you to enjoy multi-channel digital audio.



To play digital content through the HDMI connection, both the connected external device and TV must support High-bandwidth Digital Content Protection System (HDCP). This product supports HDCP.

COMPATIBILITY WITH A TV SUPPORTING HDMI	
A TV with an HDMI jack.	Video/Audio
A TV with an DVI-D jack (TV that supports HDCP)	Video
A TV with an DVI-D jack (TV that does not support HDCP)	-

HDMI Function

HDMI Audio ON/OFF function

The audio signals transmitted over the HDMI Cable can be toggled ON/OFF.



Press the **HDMI AUDIO SELECT** button on the remote control.

- This toggles between <ON> and <OFF> on the display.

- ON : Both video and audio signals are transmitted over the HDMI connection cable, and audio is output through your TV speakers only.
- OFF : Video is transmitted over the HDMI connection cable only, and audio is output through the home theater speakers only.

- The default setting of this product is HDMI AUDIO OFF.
- HDMI AUDIO is automatically down-mixed to 2ch for TV speakers.
- The HDMI AUDIO is not available when using the HDMI IN function.

What is HDMI (High Definition Multimedia Interface)?

This device transmits a DVD video signal digitally without the process of converting to analog. You will get sharper digital pictures when using an HDMI connection.

Resolution Selection

This function allows the user to select the screen resolution for HDMI output.



In Stop mode, press and hold the **SD/HD** button on the remote control.

- Resolutions available for the HDMI output are 480p, 720p,1080i and 1080p
- SD(Standard Definition) resolution is 480p and HD(High Definition) resolution is 720p/1080i/1080p.

- If the TV does not support the configured resolution, you will not be able to see the picture properly.
- See your TV owner's manual for more information on how to select the TV's Video Input source.

Before Reading the User's Manual

Make sure to check the following terms before reading the user manual.

Icons that will be used in manual

Icon	Term	Definition
DVD	DVD	This involves a function available with DVD or DVD-R/DVD-RW discs that have been recorded and finalized in Video Mode.
Super Audio CD	Super Audio CD	This involves a function available with a Super Audio CD (Single Layer, Dual Layer, Hybrid Layer).
CD	CD	This involves a function available with a data CD (CD-R or CD-RW).
MP3	MP3	This involves a function available with CD-R/-RW discs.
DivX	DivX	This involves a function available with MPEG4 discs. (DVD±R/RW, CD-R or CD-RW)
JPEG	JPEG	This involves a function available with CD-R/-RW discs.
!	CAUTION	This involves a case where a function does not operate or settings may be cancelled.
✎	NOTE	This involves tips or instructions on the page that help each function operate.

- **In this manual, the instructions marked with "DVD (DVD)" are applicable to DVD-VIDEO, DVD-AUDIO, and DVD-R/-RW discs that have been recorded in Video Mode and then finalized. Where a particular DVD type is mentioned, it is indicated separately.**
- If a DVD-R/-RW disc has not been recorded properly in DVD Video format, it will not be playable.

Before Using Your Home Theater

To Operate your Samsung TV and the Home Theater with the HT-TXQ120's Remote Control

The DVD Home Theater's remote can be used to control Samsung TVs.

1 Plug the subwoofer's power cord into the AC power supply.

- Before plugging your system into a main socket, you must check the voltage setting (OPTIONAL). If the voltage of the socket does not correspond to the setting on the rear of the unit, you may seriously damage your system.

2 Press the **TV** button to set the remote to TV mode.

3 Press the **POWER** button to turn on your Samsung TV with this remote.

4 Press the **TV/VIDEO** button to select VIDEO mode on your TV.

5 Press the **DVD RECEIVER** button to switch to DVD RECEIVER mode to operate the DVD Home Theater.

6 Press the **FUNCTION** button on the main unit or **DVD** button on the remote to enable DVD/CD playback.

: Disc Insert Hole

- Insert a disc so that the label side
- Playback starts automatically.

2 To eject the disc, press the

➢ To stop playback, press the **STOP** button during pla

- If pressed once, <PRESS PLAY> is displayed and the

If the **PLAY/PAUSE (►II)** button or **ENTER** button is
(This function works only with DVDs.)

pressed twice, **<STOP>** is displayed, and if the **PLA**
inning.

arily pause playback, press the **PLAY/P**
olayback, press the **PLAY/PAUSE (►II)**

ontent of the disc, the initial sc
n in this player because it violate

MP3/WMA-CD Playback

Data CDs (CD-R, CD-RW) encoded in MP3/WMA format can be played.



1 Load the MP3/WMA disc.

- The MP3/WMA menu screen will appear and playback will start.
- The appearance of the menu depends on the MP3/WMA disc.
- WMA-DRM files cannot be played.

2 In Stop mode, use the Cursor ▲,▼,◀,▶ button to select the album, and then press the **ENTER** button.

- Use the Cursor ▲,▼ button to select the track.

3 To change the album, use the Cursor ▲,▼,◀,▶ button to select another album in Stop mode, and then press the **ENTER** button.

- To select another album and track, repeat Steps 2 and 3 above.

4 Press the **STOP** button to stop playback.



- Depending on the recording mode, some MP3/WMA-CDs may not play.
- Table of contents of a MP3-CD varies depending on the MP3/WMA track format recorded on the disc.

➢ To play a file icon in the screen,

Press the Cursor ▲,▼,◀,▶ button when it is in Stop mode and select a desired icon from the top part of the menu.



Music File Icon : To play music files only, select the Icon.

Image File Icon : To view image files only, select the Icon.

Movie File Icon : To view movie files only, select the Icon.

All File Icon : To view movie files only, select the Icon.

JPEG File Playback

Images captured with a digital camera or camcorder, or JPEG files on a PC can be stored on a CD and then played back with this Home Theater.

Load the JPEG disc.

- Playback starts automatically. Each image is displayed for 5 seconds and then the next image is displayed.

➢ Press the ⏮ ⏭ button to skip to the next slide.

- Each time the button is pressed, the slide moves backward or forward.

Rotate/Flip Function



Press the Cursor ▲,▼,◀,▶ button during playback.


▲ button: Flip Vertically
◀ button: Rotate 90° Counterclockwise
▶ button: Rotate 90° Clockwise
▼ button: Flip Horizontally
Original Image

- The maximum resolutions supported by this product are 5120 x 3480 (or 19.0 MPixel) for standard JPEG files and 2048 x 1536 (or 3.0 MPixel) for progressive image files.

ternet video eXpress)

o file format developed by Microsoft and is based on MPEG4 compression technology to provide audio and
a over the Internet in real-time.
EG4 is used for video encoding and MP3 for audio encoding so that the users can watch a movie at near DVD-quality
video and audio.

lf both video and audio formats are not supported, the user may

MV
V7

DTS
Mbps
z

6Mbps.

o to 720X480 pixels

ience shaking on the

file (*.avi)

ese) for

DVD display
CD display
TITTLE display
TRACK (FILE) display
ELAPSED TIME display
STEREO (LR) display
MCH 2CH/Muti CH display
SUBTITLE display

Using the Playback Function (Con't)

Skipping Scenes/Songs

DVD Super Audio CD CD MP3



Press the ⏮ ⏭ button.

- Each time the button is pressed during playback, the previous or next chapter, track or directory (file) will be played.
- You cannot skip chapters consecutively.

DVD

MP3



Repeat Playback

DVD Super Audio CD CD MP3 JPEG DivX

Repeat playback allows you to repeatedly play a chapter, title, track (song), or directory (MP3 file).

Press the **REPEAT** button.

- Each time the button is pressed during playback, the repeat playback mode changes as follows:

DVD-VIDEO	REPEAT : CHAPTER → REPEAT : TITLE → REPEAT : OFF
DVD-AUDIO	REPEAT : TRACK → REPEAT : GROUP → REPEAT : OFF
Super Audio CD	REPEAT : DISC → REPEAT : TRACK → REPEAT : OFF
CD	REPEAT : TRACK → REPEAT : DISC → REPEAT : OFF
MP3 JPEG DivX	REPEAT : RANDOM → REPEAT : TRACK → REPEAT : DIR → REPEAT : DISC → REPEAT : OFF

Repeat Playback Options

CHAPTER : Repeatedly plays the selected chapter.

TITLE : Repeatedly plays the selected title.

GROUP : Repeatedly plays the selected group.

RANDOM : Plays tracks in random order.
(A track that has already been played may be played again.)

TRACK : Repeatedly plays the selected track.

DIR : Repeatedly plays all tracks in the selected folder.

DISC : Repeatedly plays the entire disc.

OFF : Cancels Repeat Playback.

To Select a Repeat Playback Mode in the Disc Information Screen

DVD Super Audio CD CD



1 Press the **INFO** button twice.

2 Press the Cursor ▶ button to move to the REPEAT PLAYBACK ( ) display.

3 Press the Cursor ▼ button to select the desired Repeat Playback mode.

- To select another album and track, repeat Steps 2 and 3 above.

4 Press the **ENTER** button.

DVD

Super Audio CD CD



- For Divx, MP3 and JPEG discs, you cannot select Repeat Play from the information display screen.



Using the Playback Function (Con't)

EZ VIEW Function



Press the **EZ VIEW** button.

- Each time the button is pressed, the zoom function will switch between On and Off.
- When a movie is played in Widescreen format, black bars at the top and bottom of the TV screen can be removed by pressing the EZ VIEW button.

- This function will not work if the DVD is recorded with multi-camera angle format.
- Black bars may not disappear because some DVD discs have a built-in horizontal to vertical ratio.
- This feature is not supported for DivX discs.
- During the EZ View operation, some of the left and right sides may be cut slightly.

Bonus Group

Some DVD-Audio discs have an extra 'bonus' group that requires a 4-digit key number to access. See the disc packaging for details and the-key number.

When you play a DVD-Audio disc that has a bonus group, the key number input screen appears automatically.

- If you eject the disc, switch the power off, or unplug the player, you will need to re-enter the key number.

During playback, press the button on the remote control.

- You can select the desired image from a DVD-Audio disc containing still images.
- With some discs, you may not be able to select images.

Using the Playback Function (Con't)

Moving Directly to a Scene/Song



1 Press the **INFO** button.

2 Press the Cursor ▲, ▼ button or numeric buttons to select the desired title/track and then press the **ENTER** button.

3 Press the Cursor ◀, ▶ button to move to the Chapter ( ) display.

4 Press the Cursor ▲, ▼ button or numeric buttons to select the desired chapter and then press the **ENTER** button.

5 Press the Cursor ◀, ▶ button to move to time ( ) display.

6 Press the numeric buttons to select the desired time and then press the **ENTER** button.

Press the **numeric** buttons.

Playing Media Files using the USB HOST Feature

You can enjoy media files such as pictures, movies and music saved in an MP3 player, USB memory or digital camera in high quality video with 5.1 channel home theater sound by connecting the storage device to the USB port of the home theater.



1 Connect the USB device to the USB port on the back of the unit.

2 Press the **FUNCTION** button on the main unit or the **USB** button on the remote control to select the USB mode.

- "USB" appears on the display screen and then disappears.
- The USB MENU screen appears on the TV screen and the saved file is played.

3 To stop playback, press the **STOP** (■) button.

➢ Safe USB Removal

To prevent damage to the memory stored in the USB device, perform safe removal before disconnecting the USB cable.

(1) Press the **STOP** (■) button twice in a row.
The display will show **REMOVE→USB**.
(2) Remove the USB cable.

Supported Formats

- CBI (Control/Bulk/Interrupt) is not supported.
- Digital Cameras that use PTP protocol or require additional program installation when connected to a PC are not supported.
- A device using NTFS file system is not supported. (Only FAT 16/32 (File Allocation Table 16/32) file system is supported.)
- Some MP3 players, when connected to this product,may not operate depending on the sector size of their file system.
- The USB HOST function is not supported if a product that transfers media files by its manufacturer-specific program is connected.
- Does not operate with Janus enabled MTP (Media Transfer Protocol) devices.
- **The USB host function of this product does not support all USB devices.**
  For information on the supported devices, see page 68.

Settings

Setting the Language

OSD(On-Screen Display) language is set to English by default.

1 In Stop mode, press the **MENU** button.

2 Press the Cursor ▼ button to move to **<Setup>** and then press the **ENTER** button.

3 Select **<LANGUAGE>** and then press the **ENTER** button.

4 Press the Cursor ▲, ▼ button to select **<OSD LANGUAGE>** and then press the **ENTER** button.

5 Press the Cursor ▲, ▼ button to select the desired language and then press the **ENTER** button.

- Once the setup is complete, the OSD will be English if English has been selected as language.

➢ Press the **RETURN** button to return to the previous level.

➢ Press the **MENU** button to exit the setup screen.

- OSD LANGUAGE : Selecting the OSD Language
- AUDIO : Selecting the Audio Language (recorded on the disc)
- SUBTITLE : Selecting the Subtitle Language (recorded on the disc)
- DISC MENU : Selecting the Disc Menu Language (recorded on the disc)

※ If the language you selected is not recorded on the disc, the menu language will not change even if you set it to your desired language.

- OTHER : To select another language, select OTHER and enter the language code of your country. (See page 67 for language codes) AUDIO, SUBTITLE and DISC MENU language can be selected.

Setting TV Screen type

Depending on your TV type (Wide Screen or conventional 4:3), you can select the TV's aspect ratio.

1 In Stop mode, press the **MENU** button.

2 Press the Cursor ▼ button to move to **<Setup>** and then press the **ENTER** button.

3 Press the Cursor ▼ button to move to **<TV DISPLAY>** and then press the **ENTER** button.

4 Press the Cursor ▲, ▼ button to select the desired item and then press the **ENTER** button.

- Once the setup is complete, you will be taken to the previous screen.

➢ Press the **RETURN** button to return to the previous level.

➢ Press the **MENU** button to exit the setup screen.

Adj usting the TV Aspect Ratio (Screen Size)

The horizontal to vertical screen size ratio of conventional TVs is 4:3, while that of widescreen and high definition TVs is 16:9. This ratio is called the aspect ratio. When playing DVDs recorded in different screen sizes, you should adjust the aspect ratio to fit your TV or monitor.

For a standard TV, select either <4:3LB> or <4:3PS> option according to personal preference. Select "16:9" if you have a widescreen TV.

WIDE
Select this to view a 16:9 picture in the full-screen mode on your widescreen TV.
- You can enjoy the widescreen aspect.

4:3LB (4:3 Letterbox)
Select this to play a 16:9 picture in the letter box mode on a conventional TV.
- Black bars will appear at the top and bottom of the screen.

4:3PS (4:3 Pan&Scan)
Select this to play a 16:9 picture in the pan & scan mode on a conventional TV.
- You can see the central portion of the screen only (with the sides of the 16:9 picture cut off).

- If a DVD is in the 4:3 ratio, you cannot view it in widescreen.
- Since DVD discs are recorded in various image formats, they will look different depending on the software, the type of TV, and the TV aspect ratio setting.



Settings (Con't)

DVD Playback Mode

Some DVD-Audio discs contain DVD-Video as well as DVD-Audio.
To play back the DVD-Video portion of the DVD-Audio disc, set the unit to DVD-Video mode.

1 Press the **EJECT** button and then press the **MENU** button.

2 Press the Cursor ▼ button to move to **<Setup>** and then press the **ENTER** button.

3 Press the Cursor ▼ button to move to **<DVD TYPE>** and then press the **ENTER** button.

4 Press the Cursor ▲, ▼ button to move to **<DVD VIDEO>** and then press the **ENTER** button.

■ Set steps 1 ~ 4 again if you want to switch to DVD AUDIO Play mode.

When Selecting DVD Play Mode:

• DVD VIDEO : set to play the DVD video contents contained on a DVD audio disc.
• DVD AUDIO : set to play the default DVD audio.

• DVD Play mode is set to DVD Audio as factory default setting.
• Powering off the main unit will automatically switch to the DVD Audio mode.

DivX (R) registration

Please use the Registration code to register this player with the DivX (R) video on demand format.
To learn more, go to www.divx.com/vod.

SACD Playback Mode

If the SACD is a HYBRID disc, you can play the disc in CDDA MODE as well.

1 Press the **EJECT** button and then press the **MENU** button.

2 Press the Cursor ▼ button to move to **<Setup>** and then press the **ENTER** button.

3 Press the Cursor ▼ button to move to **<SACD TYPE>** and then press the **ENTER** button.

4 Press the Cursor ▲, ▼ button to move to **<SACD MODE>** and then press the **ENTER** button.

■ Set steps 1 ~ 4 again if you want to switch to CDDA Play mode.

• SACD MODE : Set this mode to play SACD.
• CDDA MODE : Set this mode to play CDDA contents included in a disc.

• Powering off the main unit will automatically switch to the SACD mode.

Setting the Speaker Mode

Signal outputs and frequency responses from the speakers will automatically be adjusted according to your speaker configuration and whether certain speakers are used or not.

1 In Stop mode, press the **MENU** button.

2 Press the Cursor ▼ button to move to **<Audio>** and then press the **ENTER** button.

3 In the **<SPEAKER SETUP>**, press the **ENTER** button again.

4 Press the Cursor ▲, ▼, ◀, ▶ button to move to the desired speaker and then press the **ENTER** button.

■ For C, SL, and SR, each time the button is pressed, the mode switches alternately as follows : SMALL → NONE.

■ For L and R, the mode is set to SMALL.

• SMALL : Select this when using the speakers.
• NONE : Select this when no speakers are connected.

• Depending on PRO LOGIC and STEREO settings, the speaker mode may vary (see page 54).

Settings (Con't)

Setting the Delay Time

If the speakers cannot be placed at equal distances from the listening position, you can adjust the delay time of the audio signals from the center and rear speakers.

1 In Stop mode, press the **MENU** button.

2 Press the Cursor ▼ button to move to **<Audio>** and then press the **ENTER** button.

3 Press the Cursor ▼ button to move to **<DELAY TIME>** and then press the **ENTER** button.

4 Press the Cursor ▲, ▼, ◀, ▶ button to move to the desired speaker and then press the **ENTER** button.

5 Press the Cursor ◀, ▶ button to set the Delay time.

- You can set the delay time for C between 00 and 05mSEC and for SL and SR between 00 and 15mSEC.

➢ Press the **RETURN** button to return to the previous level.

➢ Press the **MENU** button to exit the setup screen.

Setting up the Speaker Delay Time

When 5.1CH Surround Sound is played, you can enjoy the best sound if the distance between you and each speaker is the same.
Since the sounds arrive at the listening position at different times depending on the placement of speakers, you can adjust this difference by adding a delay effect to the sound of the Center and Surround Speakers.



It is desirable to place all speakers within this circle.

Df: The distance from FRONT SPEAKER
Dc: The distance from CENTER SPEAKER
Ds: The distance from SURROUND SPEAKER

Setting CENTER SPEAKER

If the distance of Dc is equal to or longer than the distance of Df in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

Distance between Df and Dc	0 inch	13.6 inches	27.2 inches	40.8 inches	4.5 feet	5.6 feet
Delay Time	0 ms	1 ms	2 ms	3 ms	4 ms	5 ms

Setting REAR (SURROUND) SPEAKERS

If the distance of Df is equal to the distance of Ds in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

Distance between Df and Dc	0 inch	40.8 inches	6.7 feet	10.0 feet	13.4 feet	16.7 feet
Delay Time	0 ms	3 ms	6 ms	9 ms	12 ms	15 ms

- With DPL II (Dolby Pro Logic II), the delay time may be different for each mode.
- With AC-3 and DTS, the delay time can be set between 00 and 15mSEC.
- The Center channel is only adjustable on 5.1 channel discs.

Setting the Test Tone

Use the Test Tone feature to check the speaker connections.

1 In Stop mode, press the **MENU** button.

2 Press the Cursor ▼ button to move to **<Audio>** and then press the **ENTER** button.

3 Press the Cursor ▼ button to move to **<TEST TONE>** and then press the **ENTER** button.

- The test tone will be sent to L → C → R → SR → SL → SW in order.
  If the **ENTER** button is pressed again at this time, the test tone will stop.

➢ Press the **RETURN** button to return to the previous level.

➢ Press the **MENU** button to exit the setup screen.

Settings (Con't)

Setting the Audio

You can adjust the balance and level for each speaker.

1. In Stop mode, press the **MENU** button.
2. Press the Cursor ▼ button to move to **<Audio>** and then press the **ENTER** button.
3. Press the Cursor ▼ button to move to **<SOUND EDIT>** and then press the **ENTER** button.
4. Press the Cursor ▲, ▼ button to select and adjust the desired item.
   Press the Cursor ◀, ▶ button to adjust the settings.

➢ Press the **RETURN** button to return to the previous level.
➢ Press the **MENU** button to exit the setup screen.



Press the **SOUND EDIT** button and then press the Cursor ◀, ▶ button.

Adjusting Front/Rear Speaker Balance
- You can select between 0, -6, and OFF.
- The volume decreases as you move closer to –6.

Adjusting Center/Rear/Subwoofer Speaker Level
- The volume level can be adjusted in steps from +6dB to –6dB.
- The sound gets louder as you move closer to +6dB and quieter as you get closer to -6dB.

Settings (Con't)

Dolby Pro Logic II Mode

You can select the desired Dolby Pro Logic II audio mode.

Press the **PL II MODE** button.

- Each time the button is pressed, the mode changes as follows.

PRO LOGIC II

- MUSIC: When listening to music, you can experience sound effects as if you are listening to the actual performance.
- CINEMA : Adds realism to the movie soundtrack.
- PRO LOGIC : You will experience a realistic multi-channel effect, as if using five speakers, while using just the front left and right speakers.
- MATRIX : You will hear 5.1 channel surround sound.

STEREO : Select this to listen to sound from the front left and right speakers and the subwoofer only.

- When selecting Pro Logic II mode, connect your external device to the AUDIO INPUT jacks (L and R) on the player. If you connect to only one of the inputs (L or R), you cannot listen to surround sound.

- When playing a DVD disc encoded with two or more channels, multi-channel mode will be selected automatically and PL II (Dolby Pro Logic II) button does not work.

Auto Sound Calibration Setup

This function is available only for DVD/CD playback.

Auto Sound Calibration

By setting the auto sound calibration function just once when you relocate or install the unit, you can have the unit automatically recognize the distance between speakers, levels between channels, and frequency characteristics to create a 5.1-channel sound field optimized for the listener's environment.



*** The following images are for illustrative purposes only and may differ from the actual product.**

L: Front Speaker (L) R: Front Speaker (R)
C: Center Speaker SW: Subwoofer
SL: Rear Speaker (L) SR: Rear Speaker (R)

- If you have not perfomed the ASC function, pressing the Auto Sound Calibration button without connecting the auto sound calibration microphone will display the message **<PLEASE SET ASC FUNCTION>** in the display.
- Because the volume level of the tone is fixed during the auto sound calibration setup, you cannot adjust the volume using the volume control buttons.
- If the auto sound microphone is disconnected during the auto sound calibration setup, the setup will be cancelled.



A tone is output.

DIGITAL SOUND MASTER(Auto Sound Calibration)
RESULT : Center
125Hz 250Hz 500Hz 1kHz 2kHz 4kHz 8kHz 16kHz
Level : 16dB
Delay : 0.644M

A result for each speaker is displayed.

1 Connect the auto sound calibration microphone to the auto sound calibration input connector on the subwoofer.

2 Place the auto sound calibration microphone at the listener's position.

3 Press the **Volume Control** buttons on the main unit to make adjustments as below.

- If the distance between the listener and the speaker is over 194 inch : Set the main unit's volume to over 25.
- If the distance between the listener and the speaker is 118 to 194 inch : Set the main unit's volume to 25.
- If the distance between the listener and the speaker is less than 118 inch : Set the main unit's volume to 15.

4 Press the **ASC** button.

- To create the optimal 5.1 channel sound filed, the selections are in the following sequence: L → C → R → SR → SL → SW
- The auto sound calibration setup takes about 2 minutes to complete.

5 When the message **<REMOVE MIC>** appears in the display, unplug the auto sound calibration microphone.

➢ To cancel the auto sound calibration setup, press the **ASC** button.
- The tone output stops, **<CANCEL ASC>** appears in the display followed by **<REMOVE MIC>**, and the setup is cancelled.

➢ To listen in the auto sound calibration mode, briefly press the **ASC** button.
- The selection alternates between **<ASC ON>** and **<ASC OFF>** in the display.
- If you select **<ASC ON>**, you will hear sound in the auto sound calibration mode. If you select **<ASC OFF>**, you will hear sound in the mode set in the audio setting of the setup screen.

To Turn the Sound Logo On/Off

When you turn on the power, the unit produces a sound logo after the disc is read to notify that the unit is optimized for playback.



1 Press and hold the **ASC** button.
- **<S.LOGO ON>** or **<S.LOGO OFF>** appears in the display.

2 Briefly press the **ASC** button.
- Each time the button is pressed, the selection alternates between **<S.LOGO ON>** and **<S.LOGO OFF>**.
- If you select **<S.LOGO ON>**, a sound logo will be output when the disc reading is finished after power-on. If you select **<S.LOGO OFF>**, no sound logo will be output.

Live Surround Mode

Super 5.1

You can reproduce a 2-channel sound source, such as CD, and radio broadcast, in 5.1-channel surround sound.

Press the **SUPER5.1** button.

- Each time the button is pressed, the selection alternates between **<SUPER 5.1>** and **<BYPASS>**.
- Select **<SUPER 5.1>** to play 2-channel sound in 5.1 channels.

Music

If you press the MUSIC button when listening to a 2-channel sound source, it will be reproduced in 4.1-channel surround sound so that you can enjoy a dynamic sound with a sense of presence.

Press the **MUSIC** button.

- Each time the button is pressed, the selection changes as follows :

CONCERT1 → CONCERT2 → JAZZ → CATHEDRAL → BYPASS

Movie

You can select from 4 different sound field modes for movies.

Press the **MOVIE** button.

- Each time the button is pressed, the selection changes as follows :

VIRTUAL 9.1 → EX-MOVIE → CINEMA → SPORTS → BYPASS

※ VIRTUAL 9.1: Provides surround sound effect for audiences at home that simulates 9.1 channel surround sound of a movie theater.

- When you insert a DVD recorded in 2-channel or multi-channel format and press the SUPER 5.1 button, the message <**THIS FUNCTION APPLIES ONLY 2CH SOURCE**> appears in the display and it will not work.
- This function does not work with SACD or DVD-AUDIO discs.
- 5.1 channel outputs are available in VIRTUAL 9.1 or EX-MOVIE mode only.

Virtual Headphone Function

Use headphones (3.5 Ø) (not supplied) for private listening pleasure. You can enjoy dynamic sound effects similar to that of 5.1 channel surround sound using conventional stereo headphones.

1 Plug the headphones into the headphone jack.

- You can purchase headphones from most Electronics stores.



2 Press the **V-H/P** button.

- Each time the button is pressed, the selection alternates between **<V-H/P ON>** and **<V-H/P OFF>**.

• V-H/P ON : Select to enjoy a 5.1-channel surround sound that gives the feeling of being in a baseball park or concert hall.
• V-H/P OFF : Select to listen to a standard 2-channel stereo sound.

- Do not listen at extremely high volume levels when using headphones. Extended, high-volume listening can lead to permanent hearing loss.



Remote Control

Main Unit



Example : Presetting FM 89.10 in the memory

1 Press the **TUNER** button to select the **FM** band.

2 Press the ∨,∧ button to select <89.10>.

3 Press the **TUNER MEMORY** button.

- "01" flashes in the display.

4 Press the ⏮ ⏭ button to select preset number.

- You can select between 1 and 15 presets.



5 Press the **TUNER MEMORY** button again.

- Press the TUNER MEMORY button before "**number**" disappears from the display.
- "**number**" disappears from the display and the station is stored in memory.

6 To preset another station, repeat steps 2 to 5.

➢ To tune in to a preset station, press the ⏮ ⏭ button on the remote control to select a channel.

• This unit does not receive AM broadcasts.

Convenient Functions

ENG

Sleep Timer Function

You can set the time that the Home Theater will shut itself off.



Press the **SLEEP** button.

- Each time the button is pressed, the preset time changes as follows :
  10 → 20→ 30→ 60→ 90→ 120→ 150→ OFF.

➢ To confirm the sleep timer setting, press the **SLEEP** button.

- The remaining time before the Home Theater will shut itself off is displayed.
- Pressing the button again changes the sleep time from what you have set earlier.

➢ To cancel the sleep timer, press the **SLEEP** button until <OFF> appears on the display.

Adj usting Display Brightness

You can adjust the brightness of the display on the main unit so it won't interfere with your movie viewing.

Press the **DIMMER** button.

- Each time the button is pressed, the brightness of front display will be adjusted.

...ne

...15, 16, 17 and 40.

Troubleshooting

Refer to the chart below when this unit does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, turn off the unit, disconnect the power cord, and contact the nearest authorized dealer or Samsung Electronics Service Center.

Symptom	Check/Remedy
I cannot ej ect the disc.	• Is the power cord plugged securely into the outlet? • Turn off the power and then turn it back on.
Playback does not start.	• Check the region number of the DVD. DVD discs purchased from abroad may not be playable. • CD-ROMs and DVD-ROMs cannot be played on this DVD player. • Make sure that the rating level is correct.
Playback does not start immediately when the Play/Pause button is pressed.	• Are you using a deformed disc or a disc with scratches on the surface? • Wipe the disc clean.
Sound is not produced.	• No sound is heard during fast playback, slow playback, and step motion playback. • Are the speakers connected properly? Is the speaker setup correctly customized? • Is the disc severely damaged?
Sound can be heard only from a few speakers and not all six.	• When listening to a CD or radio, sound is output to the front speakers (L/R) only. Select "PRO LOGIC II" by pressing PL II (Dolby Pro Logic II) on the remote control to use all six speakers. • Make sure that the DVD disc is 5.1-CH compatible. • If you set C, SL, and SR to NONE in the speaker mode in the audio setup of the setup screen, no sound is heard from the center speaker and the front left and right speakers. Set C, SL, and SR to SMALL.
Dolby Digital 5.1 CH Surround Sound is not produced.	• Is there "Dolby Digital 5.1 CH" mark on the disc? Dolby Digital 5.1 CH Surround Sound is produced only if the disc is recorded with 5.1 channel sound. • Is the audio language correctly set to DOLBY DIGITAL 5.1-CH in the information display?
The remote control does not work.	• Is the remote control being operated within its operation range of angle and distance? • Are the batteries exhausted? • Have you selected the mode(TV/DVD) functions of the remote control (TV or DVD) correctly?

Symptom	Check/Remedy
• **Disc is rotating but no picture is produced.** • **Picture quality is poor and picture is shaking.**	• Is the TV power on? • Are the video cables connected properly? • Is the disc dirty or damaged? • A poorly manufactured disc may not be playable.
Audio language and subtitles do not work.	• Audio language and subtitles will not work for DVDs not containing them. And depending on the disc, they may work differently.
Menu screen does not appear even when the menu function is selected.	• Are you using a disc that does not contain menus?
Aspect ratio cannot be changed.	• You can play 16:9 DVDs in 16:9 WIDE mode, 4:3 LETTER BOX mode, or 4:3 PAN SCAN mode, but 4:3 DVDs can be seen in 4:3 ratio only. Refer to the DVD disc jacket and then select the appropriate function.
• **The main unit is not working. (Example: The power goes out or strange noise is heard.)** • **The DVD player is not working normally.**	• Turn off the power and hold the **STOP**(■) button on the main unit for longer than 5 seconds. **Using the RESET function will erase all stored settings. Do not use this unless necessary.**
The password for rating level has been forgotten.	• While “NO DISC” message appears on the display of main unit, hold the main unit's **STOP**(■) button for longer than 5 seconds. “INITIALIZE” appears on the display and all settings will return to the default values. • Press the POWER button. **Using the RESET function will erase all stored settings. Do not use this unless necessary.**
Can't receive radio broadcast.	• Is the antenna connected properly? • If the antenna's input signal is weak, install an external FM antenna in an area with good reception.
While listening to TV audio through the main unit, no sound is heard.	• If the eject button is pressed while listening to TV audio using the D.IN1, D.IN2, AUX functions, the DVD functions are turned on and this stops the TV audio.

Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause skipping.
Be especially careful not to scratch discs when handling them.

Handling discs

Do not touch the playback side of the disc.
Hold the disc by the edges so that fingerprints will not get on the surface.
Do not stick paper or tape on the disc.

Disc Storage

Do not keep in direct sunlight

Keep in a cool ventilated area



Keep in a clean Protection j acket. Store vertically.



- Do not allow the discs to become contaminated with dirt.
- Do not load cracked or scratched discs.

Handling and Storing Discs

When you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth.
- When cleaning, wipe gently from the inside to the outside of the disc.

- Condensation may form if warm air comes into contact with cold parts inside the player. When condensation forms inside the player, the player may not operate correctly. If this occurs, remove the disc and let the player stand for 1 or 2 hours with the power on.

Language Code List

Enter the appropriate code number for the initial settings “Disc Audio”, “Disc Subtitle” and/or “Disc Menu” (See page 44).

Code	Language	Code	Language	Code	Language	Code	Language
1027	Afar	1181	Frisian	1334	Latvian, Lettish	1506	Slovenian
1028	Abkhazian	1183	Irish	1345	Malagasy	1507	Samoan
1032	Afrikaans	1186	Scots Gaelic	1347	Maori	1508	Shona
1039	Amharic	1194	Galician	1349	Macedonian	1509	Somali
1044	Arabic	1196	Guarani	1350	Malayalam	1511	Albanian
1045	Assamese	1203	Gujarati	1352	Mongolian	1512	Serbian
1051	Aymara	1209	Hausa	1353	Moldavian	1513	Siswati
1052	Azerbaijani	1217	Hindi	1356	Marathi	1514	Sesotho
1053	Bashkir	1226	Croatian	1357	Malay	1515	Sundanese
1057	Byelorussian	1229	Hungarian	1358	Maltese	1516	Swedish
1059	Bulgarian	1233	Armenian	1363	Burmese	1517	Swahili
1060	Bihari	1235	Interlingua	1365	Nauru	1521	Tamil
1069	Bislama	1239	Interlingue	1369	Nepali	1525	Tegulu
1066	Bengali; Bangla	1245	Inupiak	1376	Dutch	1527	Tajik
1067	Tibetan	1248	Indonesian	1379	Norwegian	1528	Thai
1070	Breton	1253	Icelandic	1393	Occitan	1529	Tigrinya
1079	Catalan	1254	Italian	1403	(Afan) Oromo	1531	Turkmen
1093	Corsican	1257	Hebrew	1408	Oriya	1532	Tagalog
1097	Czech	1261	Japanese	1417	Punjabi	1534	Setswana
1103	Welsh	1269	Yiddish	1428	Polish	1535	Tonga
1105	Danish	1283	Javanese	1435	Pashto, Pushto	1538	Turkish
1109	German	1287	Georgian	1436	Portuguese	1539	Tsonga
1130	Bhutani	1297	Kazakh	1463	Quechua	1540	Tatar
1142	Greek	1298	Greenlandic	1481	Rhaeto-Romance	1543	Twi
1144	English	1299	Cambodian	1482	Kirundi	1557	Ukrainian
1145	Esperanto	1300	Kannada	1483	Romanian	1564	Urdu
1149	Spanish	1301	Korean	1489	Russian	1572	Uzbek
1150	Estonian	1305	Kashmiri	1491	Kinyarwanda	1581	Vietnamese
1151	Basque	1307	Kurdish	1495	Sanskrit	1587	Volapuk
1157	Persian	1311	Kirghiz	1498	Sindhi	1613	Wolof
1165	Finnish	1313	Latin	1501	Sangro	1632	Xhosa
1166	Fiji	1326	Lingala	1502	Serbo-Croatian	1665	Yoruba
1171	Faeroese	1327	Laothian	1503	Singhalese	1684	Chinese
1174	French	1332	Lithuanian	1505	Slovak	1697	Zulu

USB Host Feature Supported Products

Digital Camera

Product	Company	Type
Finepix-A340	Fuji	Digital Camera
Finepix-F810	Fuji	Digital Camera
Finepix-F610	Fuji	Digital Camera
Finepix-f450	Fuji	Digital Camera
Finepix S7000	Fuji	Digital Camera
Finepix A310	Fuji	Digital Camera
KD-310Z	Konica	Digital Camera
Finecam SL300R	Kyocera	Digital Camera
Finecam SL400R	Kyocera	Digital Camera
Finecam S5R	Kyocera	Digital Camera
Finecam Xt	Kyocera	Digital Camera
Dimage-Z1	Minolta	Digital Camera
Dimage Z1	Minolta	Digital Camera
Dimage X21	Minolta	Digital Camera
Coolpix4200	Nikon	Digital Camera
Coolpix4300	Nikon	Digital Camera
Coolpix 2200	Nikon	Digital Camera
Coolpix 3500	Nikon	Digital Camera
Coolpix 3700	Nikon	Digital Camera
Coolpix 4100	Nikon	Digital Camera
Coolpix 5200	Nikon	Digital Camera
Stylus 410 digital	Olympus	Digital Camera
300-digital	Olympus	Digital Camera
U300	Olympus	Digital Camera
X-350	Olympus	Digital Camera
C-760	Olympus	Digital Camera
C-5060	Olympus	Digital Camera
X1	Olympus	Digital Camera
U-mini	Olympus	Digital Camera
Lumix-FZ20	Panasonic	Digital Camera
DMC-FX7GD	Panasonic	Digital Camera
Lumix LC33	Panasonic	Digital Camera
LUMIX DMC-F1	Panasonic	Digital Camera
Optio-S40	Pentax	Digital Camera
Optio-S50	Pentax	Digital Camera
Optio 33LF	Pentax	Digital Camera
Optio MX	Pentax	Digital Camera
Digimax-420	Samsung	Digital Camera
Digimax-400	Samsung	Digital Camera
Sora PDR-T30	Toshiba	Digital Camera
Coolpix 5900	Nikon	Digital Camera
Coolpix S1	Nikon	Digital Camera
Coolpix 7600	Nikon	Digital Camera
DMC-FX7	Panasonic	Digital Camera
Dimage Xt	Minolta	Digital Camera
AZ-1	Olympus	Digital Camera

USB Flash Disc

Product	Company	Type
Cruzer Micro	Sandisk	USB 2.0 USB Flash Drive 128M
Cruzer Mini	Sandisk	USB 2.0 128M
Cruzer Mini	Sandisk	USB 2.0 256M
SONY Micro Vault	Sony	USB 2.0 64MB
FLEX DRIVE	Serotech	USB 2.0 32MB
AnyDrive	A.L tech	USB 2.0 128MB
XTICK	LG	USB 2.0 128M
Micro Mini	Iomega	USB 2.0 128M
iFlash	Imation	USB 2.0 64M
LG	XTICK(M)	USB 2.0 64M
RiDATA	EZDrive	USB 2.0 64M

MP3 Player

Product	Company	Type
Creative MuVo NX128M	Creative	128 MB MP3 Player
Iriver H320	Iriver	20G HDD MP3 Player
YH-920	Samsung	20G HDD MP3 Player
YP-T7	Samsung	MP3 Player
YP-MT6	Samsung	MP3 Player
YP-T6	Samsung	MP3 Player
YP-53	Samsung	MP3 Player
YP-ST5	Samsung	MP3 Player
YP-T5	Samsung	MP3 Player
YP-60	Samsung	MP3 Player
YP-780	Samsung	MP3 Player
YP-35	Samsung	MP3 Player
YP-55	Samsung	MP3 Player
iAUDIO U2	Cowon	MP3 Player
iAUDIO G3	Cowon	MP3 Player
iAudio M3	Cowon	HDD MP3 Player
SI-M500L	Sharp	256MB MP3 Player
H10	Iriver	MP3 Player
YP-T5 VB	Samsung	MP3 Player
YP-53	Samsung	256MB MP3 Player

USB External HDD

Product	Company	Type
MOMOBAY UX-2	Dvico	USB 2.0

Specifications

GENERAL	Power Consumption	110W
	Weight	11 lbs
	Dimensions (W x H x D)	20.5 in.x 12.6 in.x 7 in.
	Operating Temperature Range	41°F ~ 95°F
	Operating Humidity Range	10% ~ 75%
FM TUNER	Usable Sensitivity	10dB
	S/N Ratio	60dB
	Distortion	0.5%
VIDEO OUTPUT	Composite Video	1.0Vp-p(75Ω load)
	Component Video	Y:1.0Vp-p(75Ω load)
		Pr:0.70Vp-p(75Ω load)
		Pb:0.70Vp-p(75Ω load)
	HDMI	Impedance: 85~115
AMPLIFIER	Front speaker output	167W x 2(3Ω)
	Center speaker output	167W(3Ω)
	Rear speaker output	167W x 2(3Ω)
	Subwoofer speaker output	165W(3Ω)
	Frequency range	20Hz~20KHz
	S/N Ratio	70dB
	Channel separation	60dB
	Input sensitivity	(AUX)500mV

SPEAKER	Speaker system	5.1ch speaker system		
		Front/Center/Rear speaker		Subwoofer speaker
	Impedance	3Ω (DCR 3.4Ω)		3Ω (DCR 3.4Ω)
	Frequency range	100Hz~20kHz		45Hz~150Hz
	Output sound pressure level	84dB/W/M		86dB/W/M
	Rated input	167W		165W
	Maximum input	334W		330W
	Dimensions (W x H x D)	Front/Rear	13.4 in.x 52 in.x 13.4 in.	10.6 in.x 16.5 in.x 19.3in.
		Center	21.7 in.x 5.4 in.x 3.3in.	
	Weights	Front/Rear	13.8 lbs	34.8 lbs
		Center	4.9 lbs	

Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

	1-800-	www.sam
	01-800	www.sam
	1-800	www.sam
	0800-	www.sam
	0800- 4004	www.sam
	800-	www.sam
	0-80	www.sam
	1-80	www.sam
	800	www.sam
	1-80	www.sam
	1-8	www.sam
	800	www.sam
	1-8	www.sam
	1-	www.sam
	1-	www.sam
	0-	www.sam
	0	www.sam
	0	www.sam
	8	u : í složka www.sam
		www.sam
		www.sam